iBook G3 14" Battery Replacement

Written By: iRobot



INTRODUCTION

Changing the battery is easy -- all you need is a coin.

TOOLS:

- Coin (1)

PARTS:

- iBook G3 14" Battery (1)

© iFixit — CC BY-NC-SA

Step 1 — Battery



- Use a coin to rotate the battery locking screw 90 degrees clockwise.
- Lift the battery out of the computer.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-16 08:50:44 PM.